

## RH450 CENTER FREQUENCY CONTROL MAP

	<b>BASS</b>	<b>LOW-MID</b>	<b>HIGH-MID</b>	<b>TREBLE</b>	
<b>-12</b>	70	100	200	400	Hz
-11	80	110	225	450	Hz
-10	90	125	250	500	Hz
-9	100	140	280	565	Hz
-8	110	160	320	635	Hz
-7	125	180	350	715	Hz
-6	140	200	400	800	Hz
-5	160	225	450	900	Hz
-4	180	250	505	1010	Hz
-3	200	280	565	1130	Hz
-2	225	320	635	1270	Hz
-1	250	360	715	1425	Hz
<b>Center</b>	<b>280</b>	<b>400</b>	<b>800</b>	<b>1600</b>	Hz
1	315	450	890	1800	Hz
2	355	500	1010	2015	Hz
3	400	565	1130	2260	Hz
4	445	635	1270	2540	Hz
5	500	715	1425	2850	Hz
6	560	800	1600	3200	Hz
7	625	900	1800	3600	Hz
8	705	1010	2000	4000	Hz
9	790	1130	2260	4500	Hz
10	885	1270	2540	5000	Hz
11	995	1425	2825	5600	Hz
<b>12</b>	<b>1120</b>	<b>1600</b>	<b>3150</b>	<b>6300</b>	Hz